OMRON

エリア スキャナ 形 F3ZP-M1N-FLK

AREA SCANNER 専用 計測コントローラ

取扱説明書

オムロン製品をお買いあげいただきありがとうございます。 この製品を安全に正しくご使用いただくため、お使いになる前 にこの取扱説明書をお読みになり、十分にご理解ください。 お読みになった後も、いつもお手元に置いてご利用ください。



オムロン株式会社

© OMRON Corporation 2002 All Rights Reserved. 6972126-0 H

■安全上のご注意

本製品は安全性に係わらない領域でご使用されることを意図 しております。本製品を以下の用途としてご使用し海外へ輸出 される場合、海外の「法律」、並びに「製造者責任」に係わる問 題が発生した場合につきましては、当社はその責を負いませ んのでご了承ください。

- 1) 作業者の手その他身体の一部が危険限界に入り負傷す ることを防ぐ用途の安全装置としての使用
- 2) 危険区域への侵入防止装置へ装着して、作業者の手その 他身体の一部を検知しドア・窓の開閉を行う検知器として の使用

■お願い

- (1) モード切り替えスイッチカバーは必ず閉じた状態でご使用 ください。
- モード切り替えスイッチを過大な力で操作しますと破損する ことがありますのでご注意下さい。
- モード切り替えスイッチカバーは取り外し式です。取り外す ときは目などを近づけないようにしてください。
- (4) この製品は分解、修理、改造をしないでください。
- (5) 形F3ZPの中には電池を使用しています。電池を火の中へ の投入などは絶対にしないで下さい。また廃棄する場合は 産業廃棄物として処理してください。

■正しい使い方

- (1)下記の設置場所では使用しないでください。
 - ① 直射日光があたる場所
 - ② 湿度が高く、結露する恐れのある場所
 - ③ 腐食性ガスのあるところ
 - ④ 本体に直接、振動や衝撃が伝わる場所 ⑤ 引火性、爆発性ガスの環境
- (2)配線・取付けについて
 - ① 通電前に電源電圧が使用最大電圧以下である事を確 認してください。
 - ② 高圧線、動力線とは別配管での使用を原則として下さ い。同一配管されると誘導を受け、誤作動あるいは破損 の原因となる場合もあります。
 - ③ コードの延長は0.3mm²以上の線を用い、100m以下 としてください。
 - ④ 形F39-MC11と同時使用しないでください。誤動作、誤設 定の原因になります。
 - ⑤ 負荷は、定格以下でご使用ください。
 - ⑥ 負荷は短絡させないでください。負荷短絡保護機能を持
 - っていますが、長時間の短絡は避けてください。 ⑦ 端子の極性を確認し、誤配線のないようにご注意くださ
 - い ⑧ 必ず定格検出距離内でご使用ください。
 - ⑨ 設定中(MODE表示点灯中)に電源を切らないでくださ
 - ⑩ 制御システムは、形F3ZPの電源投入後1秒以上経過し てから作動させてください。
 - ⑪ 電源およびF3ZPの接地はマイナス接地で接地してくださ い。

(3)清掃について

有機溶剤の使用はお避けください。

■形 F3ZP 通信設定

※無通電状態で設定変更ください。

(4)雷源について

市販のスイッチングレギュレータをご使用の際はFG(フレーム グランド端子)およびG(グランド端子)を接地してお使い下さい 接地されませんと、スイッチングノイズにて誤動作することがあ りますので、ご注意ください。

(5)本製品はクラスA製品です。家庭用環境において、本製品は電 波障害を起こすことがあります。この場合は、責任者が十分な 対策を講じてください。

RESET入力または電源再投入が必要です。

モード設定スイッチにより、通信の設定変更を行ってください。

通電状態で設定変更された場合は、エラーとなります。

ふたを開けると 設定スイッチがあります

CD-ROM ケース裏に記載してますソフトウェア使用許諾契約書に同意 していただける場合にのみケースをご開封ください。 また、設定変更を行った後は必ず動作確認を行ってください。

■機能設定支援ソフト(形 F3ZP-CD100: 別売) F3ZPには、機能設定支援を行うためのソフトウェアがあります。

変更を行うことができます。

に従ってインストールを行ってください。

→[AScan]を実行してください。

※ ソフトウェアのインストールについて

(4) 通信設定をコントローラに合わせ行ってください。

CD-ROM 内のユーザーズマニュアルを参照してください。

● 使用方法

このソフトウェアをご使用いただくことで、F3ZPの保有する機能の設定

(1) CD-ROM(形 F3ZP-CD100)内からコントローラ(形 F3ZP-M1N-FLK)の Ver.(側面に記載)に合った setup.exe を実行し、後はセットアップの指示

(CD-ROM の自動実行では、最新 Ver.の setup が起動します)

(3) インストール完了後、[スタート]→[プログラム]→[OMRON]→[AScan]

(5) 通信設定が正常に行われた後、コントローラと接続され設定が可能に

機能設定支援ソフト(形 F3ZP-CD100)の詳細な使用方法については、

(2) ご使用のパソコンと形 F3ZP をシリアルケーブルで接続してください。 シリアルケーブルは市販の RS-232C クロスケーブルがご使用いただけ

■配線図

RS-485 ケーブル配線

F3ZP

信号名

DA(-)

DB(+)

ケーブルをご使用下さい

シリアルコミュニケーションボート

24V DC

※ 使用する通信ポートはモード設定

RS-232C

クロスケーブル

RS-232C ポート

受光器コネクタ

スイッチで設定してください。

RS-485 ポート

DOS/V シリー

信号名 ピンNo.

■ 外形寸法図

(RS-232C 9P)

RS-232C ケーブル配線

シールドされたケーブルをご使用下さい

H

H

-ブルはシールド付きツイストペア

■定格			
電源電圧		DC24V ±10% リップル(p-p)10%以下	
消費電流		50mA 以下 (センサの消費電流、出力電流は除く)	
接地		D 種接地 (接地抵抗 100Ω以下) *従来の第三種接地	
接続センサ		F3ZN-S000N00-00	
センサ接続台数		最大3セットもしくは240光軸まで	
出力		負荷電源電圧 DC24V 以下、NPN オープンコレクタ出力(負荷電流 50mA 以下)	
入力		DC 入力 最大入力電圧:24V±10%	
		動作電圧 ON 電圧:最小9V / OFF 電圧:最大 1.5V 、入力電流 3mA 以下	
プログラマブル入出カポート		アプリケーションにより、使用目的が異なります	
(D**)		出力:負荷電源電圧 DC 24V 以下、NPN オープンコレクタ出力(負荷電流 30mA 以下)	
		入力:DC 入力 入力電圧:24V±10%、入力電流 3mA 以下	
		動作電圧 ON 電圧:最小9V / OFF 電圧:最大1. 5V	
通信機能	接続	RS-232C ポート(D-SUB 9 ピンコネクタ)、RS-485 ポート(端子台)	
		設定スイッチでどちらか一方を主通信ポートとして使用	
		もう一方のポートも通信速度固定(9600bps)で通信可能	
	通信プロトコル	CompoWay/F	
	号機 No.	00~ 15(ロータリースイッチで設定)	
	通信速度	9600, 14400, 19200, 38400, 57600, 115200bps (スイッチにより切り替え)	
	データ構成(初期値)	データビット 7、パリティ 偶数、スタートビット 1、ストップビット 2、フロー制御 無し	
表示灯		POWER: 緑、MODE: 緑、RUN: 緑、ERROR: 赤	
保護回路		電源逆接続保護、出力短絡保護	
応答時間(プログラマブル I/O)		センサの制御出力 1(OUT1) ON → OFF の応答時間 × 3 (センサの接続数に関係なく)	
周囲温度		使用時:-10 ~ 55℃ 保存時:-20 ~ 75℃	
周囲湿度		使用時、保存時:10 ~ 90%RH (結露しないこと)	
絶縁抵抗		20MΩ以上 (DC500V メガー) 全端子ーケース間	
耐電圧		AC1000V 50 / 60 Hz 1 分間 漏れ電流 10mA 以下	
ケースの材質		ABS / PC	
付属品		RS-232C コネクタ(プラグ、カバー)、取扱説明書	

接続する外部機器

信号名

DA

DB

RS-485 ケーブル

■入出力回路 F3ZP-M1N-FLK COM OUT %6 端字台 +24V gramable ※1 I/O 0V 30mA Max FG COM OUT %6 F3ZP INPUT **%**2 制御 回路 負 荷 COM IN %7 OUTPUT 50mA Max EDI ¾4 主制御回路 負荷 受光器 OUT1 %5 センサ投光器 50mA Mar 負荷 OUT2 **%**5 50mA Max

※1:プログラマブル I/0(D00~D15)は入力、出力共に使用可能となっています。 現在は出力としてのみ使用可能です。判定結果や、計測結果を割付けてご使用

ください。

※2: INPUT は RESET, TCH, BANK1, BANK2, BANK IN が対応しています。 ※3:OUTPUT は OUT3, ERROR, TCH OUT, BANK OUT が対応しています。

※4:センサの入力がそのまま端子に接続されています。

※5:センサの出力がそのまま端子に接続されています。

※6:COMOUT は+24V に接続されています。

※7:COMIN は OV に接続されています。

■参照マニュアル

AREA SCANNER ユーザーズマニュアル

AREA SCANNER を安全に正しくお使いいただくための情報、パ ッケージの内容~設置~接続までの手順、設定ソフトウェアの 使用法、通信リファレンス、本体やセンサの性能や仕様の情報 などについて記載しています。

(マニュアル番号 SCHG-701 □)

号機番号 設定スイッチ

データビット長設定

- ストップビット長設定

〉 OFFでご使用ください

終端抵抗スイッチ

- パリティ設定

3 🔳

4 🔳

6

CompoWay/Fで使用する号機番号

シリアル通信(CompoWay/F)で使用する号機番号は、図の 号機番号設定スイッチ(ロータリースイッチ)によって設定します。 ロータリースイッチと号機番号の関係は以下の通りとなります。



通信速度

DIP SW の 1 ~ 3 を使用して設定します

211 1 3 2 22/10 (12/2007)			
DIP SW No.			_
1	2	3	スピード
OFF	OFF	OFF	9600bps(初期値)
ON	OFF	OFF	14400bps
OFF	ON	OFF	19200bps
ON	ON	OFF	38400bps
OFF	OFF	ON	57600bps
ON	OFF	ON	115200bps

主通信ポート

DIP SW No.4 を使用して設定します。 DIP-SW No.4 主通信ポート

	OFF	110 2020 (7)799] [直7	
	ON	RS-485	
デ	一タビット長		
	DIP SW No.5 を使用して設定します。		
	DIP-SW No.5	データビット長	
	OFF	7(初期値)	

パリティ

DIP SW No 6 を使用して設定します DIP-SW No.6 パリティ OFF 偶数(初期値) ON 無し

ストップビット長

DIP SW No.7 を使用して設定します DIP-SW No.7 ストップビット長 OFF 2(初期値) ON

終端抵抗

DIF SW NO.0 を使用して放走しまり。		
DIP-SW No.0	終端抵抗	
OFF	未接続(初期値)	
ON	接続	
WAR DURE LIVE THE COLOR TO COL		

一番端のコントローラのみ ON にしてください。

ご使用に際してのご承諾事項

ŀΦ

F3ZN シリーズ

投光器

RS-485 端子

モード設定

スイッチ

0

投光器コネクタ

DA/DB

第3種接地

1914 000000000

A KARAMAN KANKAN KANKAN

 $D00{\sim}D15$

接続

PLC, 負荷などへ

受光器

Õ

 \odot

38. 1

オムロン株式会社

下記用途に使用される場合、当社営業担当者までご相談のうえ仕様書 などによりご確認いただくとともに、定格・性能に対し余裕を持った使い 方や、万一故障があっても危険を最小にする安全回路などの安全対策 を講じてください。

a)屋外の用途、潜在的な化学的汚染あるいは電気的妨害を被る用途ま たはカタログ・取扱説明書などに記載のない条件や環境での使用 b)原子力制御設備、焼却設備、鉄道·航空·車両設備、医用機械、娯楽

機械、安全装置、および行政機関や個別業界の規制に従う設備 c)人命や財産に危険が及びうるシステム・機械・装置

d)ガス、水道、電気の供給システムや 24 時間連続運転システムなど高 い信頼性が必要な設備

e)その他、上記a)~d)に準ずる、高度な安全性が必要とされる用途 *上記は適合用途の条件の一部です。当社のベスト、総合カタログ、データー シート等最新版のカタログをよく読んでご使用ください。

現在販売されていないオプション・アクセサリ・消耗品等が記載されて また記載されている営業拠点の電話番号等は変更されています。 お問い合わせはつぎのフリーコールでお願いいたします。


カスタマサポートセンタ

営業統轄事業部

60120-919-066

■営業時間:8:00~21:00(365日) 携帯電話、PNSなどではご利用になれませんので、その場合は下記におかけください。 電話: 055-982-5015 (通話料がかります) オムロン株式会社 インダストリアルオートメーションビジネスカンパニー

●その他のお問い合せ先 納期・価格・能理・サンブル・承認図は貴社のお取引先、 または貴社担当オムロン営業員にご相談ください。 (P)



OMRON

Model

F3ZP-M1N-FLK

INSTRUMENTATION CONTROLLER dedicated use for AREA SCANNER

INSTRUCTION SHEET

Thank you for selecting OMRON product. For proper and safe use of this product read this instruction sheet thoroughly to become aware of the product and the related precautions before working for installation and operation.

After the installation, keep this sheet at the place where the operator can refer to whenever it is necessary.

OMRON EUROPE B.V. (Representative in EU) Wegalaan 67-69, 2132 JD Hoofddorp The NETHERLANDS

© OMRON Corporation 2002 All Rights Reserved.

Function Setting Support Software (Model F3ZP-CD100-E: option)

OMRON is preparing the software (AScan: option) for offering functional setting support of F3ZP. This software can perform functional setting change of F3ZP.

How to use the supporting software;

- (1) Insert CD-ROM into the computer to begin automatic installation. Follow the installation instructions. If the installer does not start up automatically, execute "Autorun.exe" of CD-ROM. (2) Connect the controller to your computer's serial interface. Use an
 - RC232Ccrossing cable.
- (3) Set up the controller for communication. Set the machine address with the rotary switch, and the communication speed and serial interface with the DIP-switches. For detailed settings, see the User's Manual.
- (4) After completing the installation, follow "Start" -> "Program" -> "OMRON" -> "AScan" -> "AScan" for execution.
- (5) Make other settings in accordance with the controller

Please refer to the Users manual in CD-ROM about the detailed usage of functional setting support software.

Function Setting Support Software (AScan) is available only if you accept the license agreement at the time of installation. Please be sure to perform a check of operation after making a setting change.

Ratings

raungs			
Supply voltage		24V DC 10% with p-p, ripples not over 10%	
Power consumption		50mA Max. (Power consumption & output current not included)	
Grounding		Grounding resistance 100 ohm or less	
Connecting sense	r	F3ZN-SxxxxNxx-xx	
No, of connecting sensor		3 sets at max. or up to 240 beams	
Output		Power voltage 24V DC or less across the load, NPN open collector output.	
•		(50mA or less of load current)	
Input		DC input Max. input voltage: 24V ± 10%, Input current; 3mA or less.	
		Operating voltage; ON voltage: 1.5V or less / OFF voltage: 9V or more.	
Programmable output/input port		Either input or output is determined according to the application.	
(D**)		Output: Power voltage 24V DC or less across the load, NPN open-collector output.	
		30mA or less of load current.	
		Input: DC input, Input voltage; 24V ± 10%, Input current: 3mA or less	
	.,	Operating voltage; ON voltage: 1.5V or less / OFF voltage; 9V or more.	
		RS-232C port (D-SUB9 pin connector), RS-485 port (terminal block)	
functions		Either of the ports to be selected by the setting switch for the main port.	
		The other port can be used at the fixed communication speed (9600bps).	
	Protocol	CompoWay/F	
	Node Number	00 to 15 to be set by rotary switch	
	Speed	9600, 14400, 19200, 38400, 57600, 115200bps to be selected by Dipswitch.	
	Data structure (initial values)	Data bit: 7, Parity: even, Start bit: 1, Stop bit: 2, Flow control: non	
Indicator		Power, RUN and Mode indicator: green, Error indicator: red	
Protective circuit		Reverse polarity of the power supply, output short-circuit	
Response time		Sensor control output 1 (OUT1) ON to OFF response time x 3	
Ambient temperature		Operating:-10 to 55 deg C Storing:-20 to 75 deg C	
Ambient humidity		Operating & storage: 10 to 90%RH (there should be no dew condensation)	
Insulation resistance		20M ohm Min. (DC500V Mega) Bet. All terminals and cases	
Dielectric withstand voltage		AC1000V 50 / 60 Hz 1/m Leakage current 10mA Max.	
Construction		IP20 or equivalent	
Case material		ABS / PC	

Cautions for Safety

This product is intended for use in the area where no particular safety measures should be concerned.

- (1) Do not use the product as a safety device for the purpose to prevent an injury when a hand or other part of human body enters into a particular hazardous area;
- (2) Do not use the product as a part of a device, machine or system in the protective application for a safety interlock mechanism.
- (3) Do not use the product as a part of a device, machine of system which must be stopped in such event of an emergency or of a hazardous occasion that a hand or other part of human body enters into a particular restricted area.
- (4) Do not use this product as the sensing device to be attached to an access control system to a particular restricted area where this product should cause a door or a window to open or close when detecting a hand or other part of human body

Requests in Use

- (1) Ensure that the cover over the mode switch is kept closed when operating the product.
- (2) Do not apply an excess force to the mode switch. Doing so may damage the switch.
- (3) The switch cover is detachable; however, do not have your eyes, etc., to come close when taking off the cover.
- (4) Do not disassemble, repair or modify this product. (5) The Model F3ZP uses batteries in the device. Never throw them in fire. For disposing the product, treat it as the industrial wastes

Proper Installation and Use

- (1) Avoid installation of this product in any of the following
 - a place directly exposed to the sunlight, a place which are humid and fears the condensation,
 - a place in corrosive gas, a place directly influenced by vibration or a shock, and,
- in an atmosphere of flammable or explosive gas.
- (2) Installation and wiring Before applying the power source to the product, be sure

to confirm that the power voltage is not higher than the specified for this product. Avoid strictly an installation of the electric source in the

same conduit with a high-tension or power line. Doing so may cause erroneous operation or damage to the product due to the electric induction. Extension cable, if used, must be no longer than 100m,

and its wire must be 3mm2 or thicker. Do not use at the same time with the Model F39-MC11. Doing so may cause erroneous operation or damage to

The load must be within the rated value. Do not short-circuit the load. The product is equipped with the protection functions against short-circuited load, though; avoid leaving it short-circuited for a long period. Confirm the terminal polarity and avoid improper wiring. Be sure to use within the rated sensing distance.


Do not turn the power OFF during the setup (while MODE indicator lights). Wait for (1) second after turning the power ON for the Model F3ZP, and then activate the control system. Ground grounding of a power supply and F3ZP by minus

arounding. (3) Cleaning

the product.

- Do not use organic solvent for cleaning.
- (4) Other precaution with power source When using a commercially available switching regulator be sure to ground the FG (ground terminal of the frame) and G (ground terminal). Failure to do so may cause
- erroneous operation due to the switching noises. (5) This is a class A product. In residential areas it may cause radio interference, in which case the Responsible Person may be required to take adequate measures to reduce interference.

Circuit configuration



- 1: The programmable I/O (D00 to D15) can be used in principle both for input and output; however, they can be used only for the output due to the currently attached software. Determination results and measurement results can be obtained.
 2: INPUT terminals are applicable to RESET, TEACH, BANK1, BANK2, and BANK IN.
- OUTPUT terminals are applicable to OUT3, ERROR, TEACH OUT, and BANK OUT.
- '4: The sensor input is directly connected to the terminal.
- *5: The sensor output is directly connected to the terminal
- *6: COMOUT is connected to +24V.
- 7: COMIN is connected to 0V.

Reference Manuals


Area Scanner User's Manual (Manual Number Z166-E1-01)


Please refer to this manual for information of correct use of Area Scanner, detailed procedure of installation and wiring, how to use setting software, reference of communication command, and information of specification and ratings.

RS-485 cable wiring F3WP External device Signal Namo Signal Nome PLC Serial communication board RS-485 RS-485 Port Terminal DA/DB RS-485 Cable Mode selects 24V DC * Communication port to be used must be set by Mode change switch. RS-232C Cross cable RS-232C Port DOS/V Series Receiver connect RS-232C Cable wiring 0 Connect D00 to D15 Emitter connector

Dimension

Connection diagram





To PLC, Load etc

F3ZN Series


Emitter

Receive

Communication settings

Change the communication setting by using the mode setting switch. Note:

Be sure to perform the setting changes with the power OFF. If performing it with the power ON, It will end with an error. In such a case, either input by RESET or turning the power OFF-and-ON again is required.



Node No. for CompoWay/F
Specify unit No. (node No.) for serial communication (CompoWay/F) Set the node No. by the switch (rotary switch) shown above.

Refer to the table below to match the number on the switch and the node No.

Node No Rotary switch 0 (default) 9 10 13 14 Communication speed

et by Dip	SW 1 to	3	
DIP SW No.			Speed
1	2	3	Ороса
OFF	ÖFF	OFF	9600bps (default)
ON	OFF	OFF	14400bps
OFF	ON	OFF	19200bps
ON	ON	OFF	38400bps
OFF	OFF	ON	57600bps
ON	OFF	ON	115200bps

Main communication port

Set by DIP SW No.5

DIP-SW No.5

OFF

Set by DIP SW No.4 DIP-SW No.4 Main communication port OF RS-232C (default) ON Data bit length

Data bits

7 (default)

Stop bits

2 (default)

ON **Parity** Set by DIP SW No.6 DIP-SW No.6 Parity OFF Even (default) ON None Stop bit length

OFF ON

Set by DIP SW No.7

DIP-SW No.

<u>Terminal resistor</u> DIP-SW No.0 Terminal resistor No connected (default) OFF

ON Connected In case of RS-485, set Terminal resistor setting ON only for the controller at the end.

Suitability for Use

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the products in the customer's application or use of the product.

Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED. AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

See also Product catalog for Warranty and Limitation of Liability.

http://www.omron.com